Installation Sheet KSR1182/1183

installation to retain for future reference/maintainence. Read these instructions before commencing installation. Please give these instructions to the owner/occupier after

IP65 IK10 □]] **\\\\\ (€** (]0.3m**|**|| 240V~50Hz 20W

These fittings are Class II and do not require an Earth

Important Information

current IEE wiring regulations & local building control. These products are designed for connection to a 240V~50Hz supply. It is recommended that these luminaires are installed and fitted by a qualified electrician ensuring the installation complies with Any faulty, broken or damaged luminaires should be replaced immediately.

KSR will not accept responsibility for any claims arising from a poor installation

operating ambient temperature -15 - 40°C), humidity conditions, fluctuations in the electrical system or physical abuse as well as any third party to exercise caution to protect any covered product or part from outside damage, adverse temperature (normal failure related to workmanship in the installation of the products or parts. Please Note: The limited warranty shall be deemed nul and void in the following circumstances: Failure by the installer, end user or

Important User Advice

Always switch off mains supply before servicing.

lumen output. Do not use Megger or similar high voltage instruments. Due to the fact this luminaire contains electronic components that maybe damaged by high test voltages, they must be disconnected from the circuit before testing. This luminaire is suitable for exterior use, KSR recommends an atleast quarterly cleaning schedule to preserve product finish and

To prevent damage to the driver, do not mix with conventional magnetic ballasts on the same electrical circuit

At the end of life the luminaire is classed as WEEE under directive 2014/30/EU and should be disposed of in accordance with local

Installation Procedure

Safely isolate the mains supply before installation.

Remove the head by loosening the grub screw and twisting anticlockwise

Route the cable through the cable gland (8mm-12mm) and terminate wiring as per Figure 1.


Select the LED colour you require using the switch on the driver casing.

Refit the head in reverse of removal ensuring the seal is clean, in place and undamaged, grease the grub screw and tighten.

Tighten the cable gland ensuring a water tight connection.

Secure the bollard in place using suitable fixings for the application


Turn mains supply on and test luminaire.







Available finish:- Black







KSR1182

KSR1183

200mm

Lamp Details

Lamp: Dedicated LED

Wattage: 20W

Colour: Switchable 3000K - 4000K - 6000K

6000K Lumen Output: 1535 lumens 4000K Lumen Output: 1724 lumens 3000K Lumen Output: 1528 lumens

CRI: Ra>82

its end of life the whole luminaire shall be replaceable; when the light source reaches The light source of this luminaire is not

This product contains a light source of energy efficiency class E

KSR Lighting Aftersales: 023 92 674343 E-mail: aftersales@ksrlighting.com