Installation Sheet) KSR1341

Read these instructions before commencing installation. Please give these instructions to the owner/occupier after installation to retain for future reference/maintainence.

Available finish: - 304 Stainless Steel

60mm

60mm

27mm

Tulua III 🕻 🖁 🕽 🕽 GU10 Stainless Steel Range

These fittings are Class I and must be Earthed |P44 (士) **LK** (€ (0.5m | 240VAC~50Hz 2x35W Max.

Important Information

control. These products are designed for connection to a 240V~50Hz supply. It is recommended that these luminaires are installed and fitted by a qualified electrician ensuring the installation complies with current IEE wiring regulations & local building


Any faulty, broken or damaged luminaires should be replaced immediately.

KSR will not accept responsibility for any claims arising from a poor installation.

of the products or parts. fluctuations in the electrical system or physical abuse as well as failure related to workmanship in the installation damage, adverse temperature (normal operating ambient temperature -20 ~ +40°C), humidity conditions installer, end user or any third party to exercise caution to protect any covered product or part from outside Please Note: The limited warranty shall be deemed null and void in the following circumstances: Failure by the

Base Section This Way Up

26mm



220mm

162mm

182mm

General Maintenance

General maintenance and cleaning should be performed at least quarterly.

maintenance or lamp replacement, remember to check all seals are intact. deposits may build up on the surface, this can be cleaned off to return the product to it's original look. After any Clean product outer using a damp cloth, dried and buffed to a shine. As a raw finished material atmospheric

Installation Procedure

fitting to the mounting plate. Familiarize yourself with the luminaire, remove the two chrome dome nuts that secure the main

Set aside the dome nuts.

holes at the bottom of the plate. Offer the base plate up to a suitable surface and mark the four fixing points, ensuring the drain

Minimum On Lux - 9 Lux

Viewing Angle - 110°

Range - 9M when mounted at 4M PIR Settings
Switch Time - 12 Sec to 4 Minutes


Ensure the main gasket is seated correctly on the base plate and place the fitting onto it, refit and Once drilled, dress the mains supply cable through the grommet and secure to the wall Terminate the mains supply into the terminal block, following the markings on the fitting

tighten the dome nuts.


Remove the caps and fit GU10 lamps, if using GU10 LED lamps ensure they are suitable for enclosed housings. Refit the caps, please check they are secure to ensure a good sea

Lux to suit, close the hood. Flip the small hood on the PIR down to access the PIR settings, adjust the Time, Sensitivity, and

Turn on the power and test the luminaire







Suitable for Retrofit LED Lamps Lamp Cap: GU10 Max Wattage: 35W

E-mail: aftersales@ksrlighting.com KSR Lighting Aftersales: 023 92 674343