Installation Sheet) KSR1310-1311

Tulua GU10

Available Finishes: 316 Stainless Steel

GU10 Stainless Steel Floor Lamp

installation to retain for future reference/maintainence. Read these instructions before commencing installation. Please give these instructions to the owner/occupier after



These fittings are Class I and must be Earthed

Important Information

current IEE wiring regulations & local building control. These products are designed for connection to a 240V~50Hz supply. It is recommended that these luminaires are installed and fitted by a qualified electrician ensuring the installation complies with Any faulty, broken or damaged luminaires should be replaced immediately.

KSR will not accept responsibility for any claims arising from a poor installation.

installation of the products or parts. humidity conditions, fluctuations in the electrical system or physical abuse as well as failure related to workmanship in the Please Note: The limited warranty shall be deemed null and void in the following circumstances: Failure by the installer, end user or any third party to exercise caution to protect any covered product or part from outside damage, adverse temperature

Important User Advice

Always switch off mains supply before servicing.

KSR recommend greasing all threaded parts and cleaning the body every 3 months minimum.

local legislation At the end of life the luminaire is classed as WEEE under directive 2014/30/EU and should be disposed of in accordance with

Installation Procedure

luminaire. Familiarize yourself with the luminaire/installation procedure and ensure the power is safely isolated before installing the

The pre-wired connector can be found in the post of the fitting


Remove the connector cover by taking out the four screws ensuring you retain the top and sea


Connect to the mains supply (KSR recommend for external use with larger cables that you use a suitably IP rated connector)

Re-attach the top of the connector ensuring the seal is in place.

Unscrew the lamp cap (anti-clockwise) fit lamp (maximum 35W) and re-fit lamp cap ensuring that the seal is in place. Secure the base in position using suitable fixings for the substrate.

Turn on mains supply and test luminaire.









E-mail: aftersales@ksrlighting.com KSR Lighting Aftersales: 023 92 674343